

#3963 FACTORY TEAM THREADED SHOCK KIT

1 Slide one black O-ring into the groove in the threaded shock collar.



2 Use one drop of oil on the O-ring before you thread on the shock collar.



3 Carefully thread on the shock collar. Make sure that the shoulder is facing down when threaded on the body.

shoulder faces down



TEAM ASSOCIATED
3585 Cadillac Ave.
Costa Mesa, CA 92626



phone: (714) 850-9342
fax: (714) 850-1744
web: <http://www.teamassociated.com>