

#91605 CVA Axle Shims Supplement

CVA Axle Shims:

It is recommended that you use #91605 CVA Axle Shims when using #91608 FT Aluminum Arm Mount.

You must use both shims when installing the #91605 CVA Axle Shim Kit.

This will decrease the chances of the dog bones popping out of the outdrives.

Install on both left, and right CVA's as shown.

