

#6137 MERCEDES WING ASSEMBLY & INSTALLATION

Cut out the wing and two wing end plates that are attached to the back of your Mercedes body. You can either glue or servo tape the end plates to the sides of the wing. Drill or slot the wing mounting holes and drill holes in the two wing posts on the body. If you slot the wing you can adjust the wing angle to increase or decrease rear down force. Then mount the wing to the body with the following hardware:

two #6919 4-40 x 5/16 button head socket screws, two #6936 #4 aluminum flat washers and two #6295 4-40 steel locknuts.

AE TEAM ASSOCIATED

