



#6193 Aluminum Super Wing Things

When installing on the #9455 .078" B2 wing wire, chamfer the bottom edge of both sides of the wing wire hole as shown at right with your X-acto® knife. Do not straighten the .078" wing wire or it will break. If you still have difficulty rounding the wire corners, just chamfer more of the hole until you have the clearance you need.



Cut chamfer here, both sides of tube

