

#6371 UNIVERSAL DOGBONE/DRIVESHAFT STUB AXLE INSTRUCTIONS

STEP 1 Slip the large washer (d) onto the drive shaft (e) and then slip the driveshaft into the oiled bushing or ball bearings inserted into your hub carrier (c).

STEP 2 Now slip up to four of the small washers (b) onto the axle (e) so you end up with just a small amount of end play between the washers (b) and the roll pin (a).

STEP 3 Press in the roll pin (a)—a small pliers will help here. There should be just a very small amount of side play when you're done. If it's too loose, add another washer; if it's too tight, take a washer out. Do the same with the other side.

