

SUPPLEMENTARY SHEET

For the RC10GT

Instructions for the Reverse Fill Fuel Tank

Replace page 26, Bag O, step 10 with these instructions.

step 10

FUEL TUBING

- 1 Slide one end of the #7724 fuel tubing onto the fuel tank outlet fitting nearest the tank opening. Bring the other end of the tubing over to the carb fitting. When you have the correct length without kinks in the tubing or rubbing against other parts of the truck, then mark the fuel tubing and cut it to that length. Again check to make sure the fuel line clears the spur gear or any other parts.

- 2 Install the tubing into the fitting on top of the fuel tank.
- 3 Take one of the small #7709 wire ties and loop it around the muffler bracket, leaving as large a loop in it as possible. Take your fuel tubing and run it through the wire tie, then loop it around and bring it back through the same side of the wire tie again.
- 4 Now take the end of the tubing and squeeze it into the hole in the #7730 tuned pipe muffler about 3/8."
- 5 Now tighten the wire tie, but not so tight that it will begin to compress the tubing. Cut off the end of the wire tie.

