

# 1:18 Scale Conversion Guide



## RC18T

convert

**18T to 18MT** 16 8 1 3 9

**18T to 18B** 14 7 10 11 6 5

**18T to 18R** 13 17 18 19 20 21 22 23 24 25



## RC18MT

convert

**18MT to 18T** 15 25 2 12 4

**18MT to 18B** 14 7 10 11 4 25 2 5 6

**18MT to 18R** 13 17 18 19 20 21 22 23 24 25



## RC18B

convert

**18B to 18MT** 16 26 9

**18B to 18T** 15 12 26

**18B to 18R** 13 17 18 19 20 21 22 23 24 25



#21035 1



#21033 2



#21078 3



#21077 4



#21248 5



#21264 6




#21245 7



#21152 8




(2) #21065 9




(1) #21253 10



(1) #21255 11




(2) #21060 12



(2) #21291 or (2) #12192 13



#21260 or #12161 14




#21270 or #12171 15




#21072 #12139 16



#21297 or #21299 or #21293 17



#21286 18



#21287 19




#25180 20



#21282 21




#21283 22



#21284 23



#21285 24



#21159 25



#21017 26

18T, 18MT, 18B Parts List on the web

18R Parts List on the web